

# Sleepneat Bed Instructions

---



Step  
**1**

Undo the joining bolts right out that are in the joining sides as shown in the image above.

Step  
**2**

Push both pieces of the bed together and put the bolt through the hole in one side into the threaded insert nut on the other side.

Step  
**3**

Tighten up all headboard bolts making sure the ends of the bed are flush.

Step  
**4**

Lay the slat gates on top right across the bed from side to side with the fixing cleat facing down.

# Sleepneat Bed Instructions

---



Step  
**1**

Undo the joining bolts right out that are in the joining sides as shown in the image above.

Step  
**2**

Push both pieces of the bed together and put the bolt through the hole in one side into the threaded insert nut on the other side.

Step  
**3**

Tighten up all headboard bolts making sure the ends of the bed are flush.

Step  
**4**

Lay the slat gates on top right across the bed from side to side with the fixing cleat facing down.



Step 5

Undo headboard bolts in the end as shown above. Now bolt your headboard on.

Step 6

Bed can be levelled if needed by twisting the feet clockwise to lower or anti-clockwise to heighten.

Your bed is now ready for use.  
Thanks for choosing quality  
New Zealand made product. Enjoy!

Coastwood  
FURNITURE 



Step 5

Undo headboard bolts in the end as shown above. Now bolt your headboard on.

Step 6

Bed can be levelled if needed by twisting the feet clockwise to lower or anti-clockwise to heighten.

Your bed is now ready for use.  
Thanks for choosing quality  
New Zealand made product. Enjoy!

Coastwood  
FURNITURE 

